

FIBERCRETE PATCHING INSTRUCTIONS FOR PK-1 PATCH KIT

***Scuffs, chipped corners or cracks in outer surface where there is exposed glass. First remove any loose flaking of original material. Mix cement/patch material and water in pail using margin trowel to work lumps out. Ratio would be of best workability for patch area. Once mud is smooth and somewhat pasty, apply to patch area with trowel. Rubbing in with glove will help create a good bond. Apply a second coat to get a smooth finish. Touch up with wet hand or glove to blend into surrounding surface prior to curing (typically 20-30 minutes).**

***Hole patching**

Mix cement and water in pail using margin trowel to work lumps out. A stiffer Mix is recommended for larger holes.

Depending on size of hole , you may need to apply in multiple steps. Apply until Exterior of patch is at same plane as surrounding area.

A backer may be needed if hole is large enough that material falls through.

Last application should be wiped with wet hand or rubber glove to blend into surrounding surface prior to curing (typically 20-30 minutes).